

# Swim Fins & Swim Equipment

## Sizing Chart

### How to select your correct size

(For models EF4, EF8, EF40, EF50 and EF80)

FIN SIZE CHART			A	B	C	D
Australian Sizing	European Sizing	USA Sizing	Length of Foot Pocket	Width of Foot Pocket at Widest	Length of Foot Pocket Opening	Width of Foot Pocket Opening
6-8	26/29	0-0	19.0cm	7.0cm	7.5cm	4.5cm
8-11	30/33	0-1	19.0cm	7.2cm	8.0cm	5.0cm
11-1	34/35	1-3	20.0cm	7.5cm	8.0cm	5.5cm
1-3	36/37	3-5	21.0cm	8.0cm	8.5cm	5.5cm
3-5	38/39	5-7	22.0cm	8.5cm	9.0cm	6.0cm
5-7	40/41	7-9	23.0cm	9.0cm	9.5cm	6.5cm
7-9	42/43	9-11	25.0 cm	9.5cm	10.0cm	7.0cm
9-11	44/45	11-13	26.0cm	10.0cm	11.0cm	7.5cm
11-13	46/48	14-15	27.0cm	10.5cm	11.5cm	8.0cm
13-15	49/51	16-17	29.0cm	11.0cm	12.0cm	8.0cm
15-17	51/53	17-18	30.0cm	11.0cm	13.0cm	8.0cm
17-19	53/55	19-20	31.5cm	11.7cm	14.0cm	9.0cm

### Notes

1. Eyeline uses only Australian Sizing as its reference sizing.
2. Sizes shown in above chart are male sizes.
3. For female sizing we suggest you select 1 size down, for example a female 7-9 size equals a male 5-7 size.

### Care for your fins

1. Avoid prolonged exposure to direct sunlight.
2. Don't leave near a heat source.
3. Rinse in fresh water after each use.
4. Never expose to chemicals or solvents.
5. To give them a good clean ONLY use mild soap and water or a rubber cleaner/preservative.

